TROUBLESHOOTING GUIDE

IG3110 1000W Travel Iron

Problem	Possible Cause	Solution
The iron does not work.	1. Not properly plugged into the mains wall socket. 2. No electricity in the mains wall socket.	1. Plug in firmly. 2. Check fuse or breaker.
The iron leaks and there is not much steam produced.	1. The thermostat is set too low. 2. The water tank is too full. 3. The water in your area is hard and has caused a mineral deposit build up in the iron.	1. Turn the thermostat to a higher setting. 2. Empty some water out of the water tank. 3. Follow the 'Care and Cleaning' section to remove deposits and consider using de-mineralized water.
The iron does not remove creases.	1. Temperature is set too low for the type of fabric you are ironing. 2. The material is too dry to be ironed.	1. Turn up the thermostat slightly until the iron removes the creases. Do not set the iron temperature higher than what is advised on the garment. 2. Use the spray button to dampen the crease.